

Wanderful Nebuliser

– Dusty Rose

Item No. 51840

Wherever you wander, create your own kind of wonderful with the Wanderful Nebuliser. Combining the latest diffuser technology and innovative anti-leak design with an elegant, fluted finish, dusty rose hue, and a handy leather strap for easy portability.

Totally portable – Bring your favourite aromas anywhere

Long-lasting power – Enjoy up to 5 hours of run time

USB-powered – Comes with a USB cord

Spill-free peace of mind – Anti-leak technology keeps your space mess-free

No water needed – Just essential oil diffusion at the touch of a button

Smart and safe – Auto shut-off feature gives you worry-free use every time

Whisper quiet – Silent operation means it won't disturb your vibes



Benefits and Features

- Completely portable and rechargeable.
- Includes a USB power cord.
- Charging time up to 6 hours and battery time 18 hours.
- Features clearly visible light indicators on the top of the device for easy mode selection and operation.
- Features anti-leak technology.
- No water required.
- Auto-turn off safety feature.
- Silent operation.
- Suitable for 5 ml, 10 ml, or 15 ml essential oil bottles.
- Easy to use with simple run times.
- Time setting: low mode runs for 1 hour, mid mode runs for 2 hours, while high mode runs for 5 hours.
- Misting level: low mode: 6 seconds on/54 seconds off, mid mode: 13 seconds on/47 seconds off and high mode: 4 minutes on/6 minutes off.



Wanderful Nebuliser – Dusty Rose

Directions

1. Slide the nozzle upward and remove the empty bottle.
2. Fill the empty bottle or replace it with a bottle of your favourite essential oil.
3. Screw the bottle onto the nozzle, rotating the bottle counterclockwise to secure.
4. Slot the nozzle (with bottle) back into the diffuser, lining it up with the indicator mark.
5. Plug the nebuliser to a power source or use the battery if you're on the go.
6. Press the On/Off button once to start the device.
7. Press the button to change the mist output from low to mid/high.
8. Turn off the diffuser by pressing the button a fourth time or wait for it to shut off automatically at the end of the run time.



Cautions

For safety and care information, refer to the user manual.

Contents

1 x Diffuser

1 x USB Cable Type C

