



ARIA ULTRASONIC DIFFUSER


How to Change the Membrane with the Key




1. Position the key on top of the gasket. Adjust the key until it settles into position;




2. Unscrew the gasket by turning the key counterclockwise;




3. Remove the old membrane;



4. Replace with a new one with front side facing up;



5. Reverse the sequence;



6. Fasten the membrane by turning the key clockwise and replacing is now complete.

