

Ultrasonic Diffuser

USER MANUAL
GEBRAUCHSANLEITUNG
BRUKSANVISNING
MANUAL DEL USUARIO

• English • Deutsch • Svenska • Español



YOUNG  LIVING
ESSENTIAL OILS

Introduction

Contents

Product Features

Safety Instructions

Components Descriptions

Solving Problem DIY

Operating Instructions

Specifications

How to use

Using clean filtered water, add one cupful (236ml) to the bowl. Water should reach the top of the level indicator on the side of the bowl. Add 15–20 drops of any essential oil single or blend. Plug the adapter into the socket at the rear of the diffuser. Do not power the diffuser until the bowl is correctly filled with water.

Product Specifications

External Dimension	17.5cm * 15cm * 11cm
Transformer	110V/24V/750mA: 220V/24V/750mA
Maximum working voltage	24V/750mA
Maximum input	18W
Operation frequency	1.7MHZ
Atomising rate	50~60
Particle size	Approx. 3 micro-meter

Controls

- * on/off switch
 - * output control in the centre; turn clockwise to increase output, turn anticlockwise to decrease
 - * Timer switch (5 settings)
- 1 Works continuously until low water level is reached and automatically enters safety stop mode
 - 2 Works continuously for 2 hours and automatically enters safety stop mode
 - 3 Dispenses for 15 seconds and rests for 40 seconds
 - 4 Dispenses for 30 minutes and rests for 15 minutes

Accessory	humidifier, transformer, dispersal nozzle, cover
Water level	0.5 cm below water blocking cover
Water level safety stop	Operates at 1.3 cm of water in tank
Capacity of tank	250 ml

Product Specifications

Problem	Solution
When switched on the Machine does not operate	<ol style="list-style-type: none"><li data-bbox="505 288 912 390">1 Check the power supply is securely plugged into the socket at the rear of the machine<li data-bbox="505 438 881 540">2 Check the mains plug is securely plugged into the wall socket<li data-bbox="505 588 923 656">3 Check the water level is correct and there is water in the tank
No dispersal or lower than usual	<ol style="list-style-type: none"><li data-bbox="505 710 891 744">1 Check for correct water level<li data-bbox="505 792 912 860">2 Check if the water level sensor is jammed<li data-bbox="505 908 912 1010">3 Check to see if the transducer is clean: do not use any cleaning agents (see instructions)<li data-bbox="505 1058 798 1092">4 Adjust output control<li data-bbox="505 1140 912 1208">5 Check to see if the top cover is securely fitted<li data-bbox="505 1256 778 1290">6 Restart the machine

Product features

Safety	No risk of over heating and/or explosion since the cool mist is generated by ultrasonic, not flame or any kind of heat
User friendly	You can set levels of output and time to your own personal settings
Operations	Once filled, the unit can operate for up to 5 hours
Digital control	To save energy and prolong product life, a digital control is designed for safety stop when water is below the recommended water level
Functions	Can be used as humidifier, atomizer and air purifier
Features	Special night-light installed

Component descriptions



1. water blocking cover
2. power on indicator
3. on/off switch
4. timer
5. output
6. time control
7. dispersal nozzle
8. water level sensor
9. cover
10. water tank
11. transducer
12. case