


AROMACONNECT™ LUNAMIST™

PLUG-IN DIFFUSER

Operation Manual

Diffuseur à brancher AromaConnect^{MC} LunaMist^{MC}

Manuel d'utilisation



Veuillez lire attentivement ce manuel d'utilisation
avant d'utiliser ce diffuseur.

Language


U.S. English	3
Kings English	15
Français	27

YOUNG LIVING®
ESSENTIAL OILS

Contents

- Diffuser
- 3 × 15 ml tubes and 1 × 5 ml tube
- Tool for removing the dropper from essential oil bottles

Overview



Overview

PLEASE READ THIS MANUAL CAREFULLY BEFORE USE

Mandatory safety procedures

- Never use this diffuser for any purpose other than what is listed in this manual.
- Read the user manual before using this diffuser.
- Remove all packaging before use.
- Prior to extended storage, be sure to remove the essential oil bottle and clean the diffuser.

WARNING: Carefully read and follow these instructions.


- This diffuser is not intended for use by persons with reduced physical or cognitive capacities with no prior experience with the diffuser unless they've received training on how to use the diffuser correctly from a person responsible for their safety and who understands the risks involved.
- Do not modify, repair, or dismantle the diffuser; fire, electric shock, or damage may occur.
- Do not expose the plug to water; burns may occur.
- Do not place fingers or any items into the plug slot.
- Stop using the diffuser immediately and remove the plug if smoke, unusual odors, unusual sounds, or other anomalies occur.
- Avoid dripping essential oil onto the exterior of the diffuser or onto furniture.
- If dripping accidentally occurs, wipe it off immediately to avoid discoloration of the exterior of the diffuser or furniture.
- This diffuser is not medical equipment. Directly inhaling the aroma mist from the spout is not recommended.
- Do not tip the diffuser upside down when oil is in the atomizer. Oil will leak.

IMPORTANT SAFETY INSTRUCTIONS WARNING

When using electric products, basic precautions should always be followed, including the following:

- a) Read all the instructions before using the product.
- b) To reduce the risk of injury, close supervision is necessary when a product is used near children.
- c) Do not put fingers or hands into the product.

SAVE THESE INSTRUCTIONS




Putting oil in your LunaMist Diffuser

1. Select the proper tube according to the height of your essential oil bottle.
2. Place the tube into the bottom of the nozzle.
3. If the essential oil bottle features a euro dropper, please use the provided tool to remove it.
4. Screw the nozzle onto the bottle with the tube inserted into the bottle.
5. Align the arrows on the nozzle and the diffuser. The nozzle should easily drop down. **DO NOT FORCE THE NOZZLE DOWN.**
6. Gently push down on the nozzle until you feel a click and the unit is ready to diffuse.

Note: This LunaMist Diffuser will perform best with lower-viscosity oils. Do not diffuse oils that contain coconut oil, as this will clog the diffuser.

Overview


Powering on your diffuser



Time


You can select how long you'd like your diffuser to run:

- 1 hour
- 2 hours
- 4 hours
- 8 hours
- Continuous: The diffuser will run continuously when no runtime lights are on.



Overview

Mist Options



Low
Medium
High

Low: 3 min at the start, 1 min every 5 minutes

Med: 5 min at the start, 2 min every 4 minutes


High: 7 min at the start, 3 min every 3 minutes

Night Light

To turn on the light, push the night-light button.

To turn off the light, push the night-light button once.

Note: The light will only activate when the room is dark.



Overview

Connecting to the Young Living AromaCare app

1. Go to the App Store (Apple) or Google Play Store (Android).
2. Download the Young Living AromaConnect app.
3. Sign in to the app and create a login.
4. Make sure you enable the Bluetooth on your phone and that the phone is connected to a 2.4 GHz Wi-Fi before pairing your mobile device to your diffuser. Most smart home devices can only connect to 2.4 GHz Wi-Fi. If you are trying to pair your device to a 5 GHz signal, you might have trouble connecting. To ensure that your device pairs correctly, make sure you are pairing your device with a 2.4 GHz Wi-Fi network.
5. Select “Connect Device” in the AromaConnect App. Press and hold the power button on your diffuser for around 3–5 seconds. Once the light starts flashing, it’ll enter pairing mode, and you can release the button.
6. Once the diffuser is paired with your mobile device, follow the in-app instructions.

Note: If you wish to set up your device in a different location, outside of the current home, residence, etc., you will need to re-pair your device to the local Wi-Fi network.

Cleaning and maintenance

- Oils can cause discoloration on parts of the diffuser. Be sure to wipe any excess oil from your device.
- To get the best performance and results, clean the nozzle 1–2 times per week or when changing the essential oil.
- For best diffusion results, use lower viscosity essential oils. Avoid any oil that contains coconut oil, this may clog your diffuser.

How to clean your diffuser:

1. Press and lift the atomizer from the LunaMist Diffuser.
2. Unscrew the oil bottle from the atomizer.
3. Pour a little rubbing alcohol in an empty essential oil bottle.
4. Screw the atomizer onto the oil bottle.
5. Push down the atomizer into the LunaMist diffuser.
6. In a well-ventilated area, turn the device on “H mode” for 30 minutes, then run it with the bottle containing rubbing alcohol for 10 minutes.
7. Remove the bottle with alcohol, re-attach a bottle containing your favorite essential oil, and enjoy.

Troubleshooting

If your diffuser isn't functioning satisfactorily, please follow the troubleshooting guidelines listed below.

Status	Cause(s)	Solution(s)
There's no mist/little mist when the diffuser is on. Note: atomizers deliver a very very fine mist - it may be hard to see to the naked eye.	Essential oil has run out.	Refill the reservoir with the appropriate amount of essential oil or replace it with new essential oil.
	The tube is installed incorrectly or it is the wrong size.	Remove and reinstall the tube. Make sure to use the correct tube.
	The diffuser has not been turned on for a long time.	Follow the instructions on cleaning and maintenance.
	There is dust on the atomizer.	
	The atomizer is not placed correctly.	Check the direction of the atomizer and install it correctly.
The diffuser doesn't turn on	The plug was not installed correctly in the adapter slot.	Detach and correctly reinstall the plug from the adapter slot.
Oil is leaking	The mist outlet is facing off level or downward.	Make sure mist outlet is always faced upward.
Diffuser releases odd smells	The atomizer emits an odd smell.	Follow the instructions on cleaning and maintenance.
	The essential oil is not clean or has been stored for a long time.	Switch out the essential oil in the diffuser for an oil in good condition.
Wi-Fi connection is unavailable	Poor internet connection.	Check the internet status or app.
	Power button doesn't blink after you press it for a long time.	Check the power is normal or not, or restart the diffuser.

Specifications

Product name:	AromaConnect™ LunaMist™ Plug-in Diffuser
Item No.:	44098
Dimensions:	103 x 81.2 x 125.3 mm / 4.06 x 3.20 x 4.93 inch
Material:	Polypropylene (PP)
Power source:	AC100-240V
Oil bottle capacity:	5–15 ml bottle
Atomized particle diameter:	Less than 3.3 UM (micrometer)
Coverage area:	Up to 400 sq. ft., depending on ceiling height, ventilation, intensity, etc.
Diffusion run time:	1 hour, 2 hours, 4 hours, 8 hours, or continuous

Young Living Diffuser Warranty

Young Living Essential Oils (YLEO), 1538 W. Sandalwood Dr., Lehi, UT 84043, subject to the exclusions contained below, warrants its diffuser to be free from defects in materials and workmanship under normal consumer usage for 12 calendar months from the date of original purchase.

This warranty does not cover:

1. Defects or damage resulting from using the diffuser in a way it's not intended to be used;
2. Defects or damage from misuse, accident, or neglect;
3. Defects or damage from using oils other than those supplied or sold by Young Living Essential Oils or an authorized distributor;
4. Defects or damage from using materials other than essential oils;
5. Defects or damage from improper testing, operation, maintenance, installation, adjustment, or any alteration or modification of any kind;
6. Breakage or damage caused by use of other than the specified voltage;

7. Products disassembled or repaired by anyone other than a Young Living Essential Oils-authorized agent so as to adversely affect performance or prevent adequate inspection, verification, and testing to verify any warranty claim. If there are any signs the diffuser has been opened, the warranty will be void.
8. Products with labels removed or illegible serial numbers;
9. Marring, such as scratches, on any plastic surfaces and externally exposed parts resulting from normal use;
10. Damage resulting from normal wear and tear;
11. Damage resulting from the use of metal tools to clean the unit.

This limited warranty is the buyer's exclusive remedy, applies to new diffusers purchased from Young Living Essential Oils, and is non-transferable. Please retain your original purchase receipt. In the event of a warranty claim or return for repair, a copy of the purchase receipt should accompany the diffuser when shipped to YLEO.

To make a warranty claim, please contact Young Living Member Services at 1.800.371.3515. Monday–Friday: 7:00 a.m.–7:00 p.m., MT. Saturday: 8:00 a.m.–5:00 p.m., MT. If it's determined by Member Services that the diffuser is to be shipped back to YLEO, the buyer will need to send the product back in its original box (if available) with the power adapter, a copy of the original purchase receipt, and the YLEO Return Merchandise Authorization (RMA#) displayed clearly on the receipt, which will be provided by Member Services.

U.S. Shipping:

Young Living Essential Oils Returns/RMA# _____
142 E. 3450 N.
Spanish Fork, UT 84660

Learn more about our return policy at YoungLiving.com/us/en/company/return-policy. For all other market addresses and contact information, visit YoungLiving.com.

NOTICE:

Please be sure to complete the YLEO return form and send back all the items listed for timely processing of your return. If YLEO has determined, based on an evaluation and inspection of the diffuser, that the defect or malfunction is covered under warranty, YLEO will send a replacement diffuser at no additional charge. In the event that the LunaMist Plug-in Diffuser is out of stock, YLEO will provide the option to exchange it for a different diffuser of comparable value or for Young Living product credit.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there's no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement.

The device can be used in portable exposure conditions without restriction.

FCC radiation exposure statement:

The equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20 centimeters, or 8 inches, between the radiator and your body.




Overview

Contents

- Diffuser
- 3 × 15 ml tubes and 1 × 5 ml tube
- Tool for removing the dropper from essential oil bottles

Overview



PLEASE READ THIS MANUAL CAREFULLY BEFORE USE

Mandatory safety procedures

- Never use this diffuser for any purpose other than what is listed in this manual.
- Read the user manual before using this diffuser.
- Remove all packaging before use.
- Prior to extended storage, be sure to remove the essential oil bottle and clean the diffuser.

WARNING: Carefully read and follow these instructions.


- This diffuser is not intended for use by persons with reduced physical or cognitive capacities with no prior experience with the diffuser unless they've received training on how to use the diffuser correctly from a person responsible for their safety and who understands the risks involved.
- Do not modify, repair, or dismantle the diffuser; fire, electric shock, or damage may occur.
- Do not expose the plug to water; burns may occur.
- Do not place fingers or any items into the plug slot.
- Stop using the diffuser immediately and remove the plug if smoke, unusual odours, unusual sounds, or other anomalies occur.
- Avoid dripping essential oil onto the exterior of the diffuser or onto furniture.
- If dripping accidentally occurs, wipe it off immediately to avoid discolouration of the exterior of the diffuser or furniture.
- This diffuser is not medical equipment. Directly inhaling the aroma mist from the spout is not recommended.
- Do not tip the diffuser upside down when oil is in the atomizer. Oil will leak.

IMPORTANT SAFETY INSTRUCTIONS WARNING

When using electric products, basic precautions should always be followed, including the following:

- a) Read all the instructions before using the product.
- b) To reduce the risk of injury, close supervision is necessary when a product is used near children.
- c) Do not put fingers or hands into the product.

SAVE THESE INSTRUCTIONS




Putting oil in your LunaMist Diffuser

1. Select the proper tube according to the height of your essential oil bottle.
2. Place the tube into the bottom of the nozzle.
3. If the essential oil bottle features a euro dropper, please use the provided tool to remove it.
4. Screw the nozzle onto the bottle with the tube inserted into the bottle.
5. Align the arrows on the nozzle and the diffuser. The nozzle should easily drop down. **DO NOT FORCE THE NOZZLE DOWN.**
6. Gently push down on the nozzle until you feel a click and the unit is ready to diffuse.

Note: This LunaMist Diffuser will perform best with lower-viscosity oils. Do not diffuse oils that contain coconut oil, as this will clog the diffuser.

Overview


Powering on your diffuser



Time


You can select how long you'd like your diffuser to run:

- 1 hour
- 2 hours
- 4 hours
- 8 hours
- Continuous: The diffuser will run continuously when no runtime lights are on.



Overview

Mist Options



Low
Medium
High

Low: 3 min at the start, 1 min every 5 minutes

Med: 5 min at the start, 2 min every 4 minutes


High: 7 min at the start, 3 min every 3 minutes

Night Light

To turn on the light, push the night-light button.

To turn off the light, push the night-light button once.

Note: The light will only activate when the room is dark.



Overview

Connecting to the Young Living AromaCare app

1. Go to the App Store (Apple) or Google Play Store (Android).
2. Download the Young Living AromaConnect app.
3. Sign in to the app and create a login.
4. Make sure you enable the Bluetooth on your phone and that the phone is connected to a 2.4 GHz Wi-Fi before pairing your mobile device to your diffuser. 5 GHz Wi-Fi isn't available for the LunaMist Diffuser.
5. Press and hold the power button on your diffuser for around 3–5 seconds. Once the light starts flashing, it'll enter pairing mode, and you can release the button.
6. Once the diffuser is paired with your mobile device, follow the in-app instructions.

Note: If you wish to set up your device in a different location, outside of the current home, residence, etc., you will need to re-pair your device to the local Wi-Fi network.

Cleaning and maintenance

- Oils can cause discolouration on parts of the diffuser. Be sure to wipe any excess oil from your device.
- To get the best performance and results, clean the nozzle 1–2 times per week or when changing the essential oil.
- Use only premium essential oils to prevent damaging the diffuser components.

How to clean your diffuser:

1. Press and lift the atomizer from the LunaMist Diffuser.
2. Unscrew the oil bottle from the atomizer.
3. Pour a little rubbing alcohol in an empty essential oil bottle.
4. Screw the atomizer onto the oil bottle.
5. Push down the atomizer into the LunaMist diffuser.
6. In a well-ventilated area, turn the device on "H mode" for 30 minutes, then run it with the bottle containing rubbing alcohol for 10 minutes.
7. Remove the bottle with alcohol, re-attach a bottle containing your favourite essential oil, and enjoy.

Troubleshooting

If your diffuser isn't functioning satisfactorily, please follow the troubleshooting guidelines listed below.

Status	Cause(s)	Solution(s)
There's no mist/little mist when the diffuser is on	Essential oil has run out.	Refill the reservoir with the appropriate amount of essential oil or replace it with new essential oil.
	The tube is installed incorrectly or it is the wrong size.	Remove and reinstall the tube. Make sure to use the correct tube.
	The diffuser has not been turned on for a long time.	Follow the instructions on cleaning and maintenance.
	There is dust on the atomizer.	
	The atomizer is not placed correctly.	Check the direction of the atomizer and install it correctly.
The diffuser doesn't turn on	The plug was not installed correctly in the adapter slot.	Detach and correctly reinstall the plug from the adapter slot.
Oil is leaking	The mist outlet is facing off level or downward.	Make sure mist outlet is always faced upward.
Diffuser releases odd smells	The atomizer emits an odd smell.	Follow the instructions on cleaning and maintenance.
	The essential oil is not clean or has been stored for a long time.	Switch out the essential oil in the diffuser for an oil in good condition.
Wi-Fi connection is unavailable	Poor internet connection.	Check the internet status or app.
	Power button doesn't blink after you press it for a long time.	Check the power is normal or not, or restart the diffuser.

Specifications

Product name:	AromaConnect™ LunaMist™ Plug-in Diffuser
Item No.:	44098
Dimensions:	103 x 81.2 x 125.3 mm / 4.06 x 3.20 x 4.93 inch
Material:	Polypropylene (PP)
Power source:	AC100-240V
Oil bottle capacity:	5–15 ml bottle
Atomized particle diameter:	Less than 3.3 UM (micrometer)
Coverage area:	Up to 400 sq. ft., depending on ceiling height, ventilation, intensity, etc.
Diffusion run time:	1 hour, 2 hours, 4 hours, 8 hours, or continuous

Young Living Diffuser Warranty

Young Living Essential Oils (YLEO), 1538 W. Sandalwood Dr., Lehi, UT 84043, subject to the exclusions contained below, warrants its diffuser to be free from defects in materials and workmanship under normal consumer usage for 12 calendar months from the date of original purchase.

This warranty does not cover:

1. Defects or damage resulting from using the diffuser in a way it's not intended to be used;
2. Defects or damage from misuse, accident, or neglect;
3. Defects or damage from using oils other than those supplied or sold by Young Living Essential Oils or an authorized distributor;
4. Defects or damage from using materials other than essential oils;
5. Defects or damage from improper testing, operation, maintenance, installation, adjustment, or any alteration or modification of any kind;
6. Breakage or damage caused by use of other than the specified voltage;

7. Products disassembled or repaired by anyone other than a Young Living Essential Oils-authorized agent so as to adversely affect performance or prevent adequate inspection, verification, and testing to verify any warranty claim. If there are any signs the diffuser has been opened, the warranty will be void.
8. Products with labels removed or illegible serial numbers;
9. Marring, such as scratches, on any plastic surfaces and externally exposed parts resulting from normal use;
10. Damage resulting from normal wear and tear;
11. Damage resulting from the use of metal tools to clean the unit.

This limited warranty is the buyer's exclusive remedy, applies to new diffusers purchased from Young Living Essential Oils, and is non-transferable. Please retain your original purchase receipt. In the event of a warranty claim or return for repair, a copy of the purchase receipt should accompany the diffuser when shipped to YLEO.

To make a warranty claim please contact Young Living Member Services at 1.800.371.3515. Monday–Friday: 7:00 a.m.–7:00 p.m., MT. Saturday: 8:00 a.m.–5:00 p.m., MT. If it's determined by Member Services that the diffuser is to be shipped back to YLEO, the buyer will need to send the product back in its original box (if available) with the power adapter, a copy of the original purchase receipt, and the YLEO Return Merchandise Authorization (RMA#) displayed clearly on the receipt, which will be provided by Member Services.

Australian Member Services:
1300 289 536 or 02 8650 0000
custserv@youngliving.com.au

Canadian Member Services:
1-855-429-2616
cxcanada@youngliving.com

Australia Shipping:
Young Living Returns /RMA# ____
PO Box 7707
Baulkham Hills BC
NSW 2153

Canada Shipping:
Young Living Essential Oils/RMA# ____
Suite 142 701 64 Ave. SE
Calgary, AB T2H 2C3

Learn more about our return policy at YoungLiving.com.

NOTICE:

Please be sure to complete the YLEO return form and send back all the items listed for timely processing of your return. If YLEO has determined, based on an evaluation and inspection of the diffuser, that the defect or malfunction is covered under warranty, YLEO will send a replacement diffuser at no additional charge. In the event that the LunaMist Plug-in Diffuser is out of stock, YLEO will provide the option to exchange it for a different diffuser of comparable value or for Young Living product credit.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there's no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement.

The device can be used in portable exposure conditions without restriction.

FCC radiation exposure statement:

The equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20 centimeters, or 8 inches, between the radiator and your body.



This device complies with Industry Canada licence-exempt RSS standard(s).

Operation is subject to the following two conditions:

- (1) This device may not cause interference, and
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.


This equipment complies with IC RF radiation exposure limits set forth for an uncontrolled environment.

This equipment should be installed and operated with a minimum distance of 20 centimeters between the radiator and your body.

Contenu

- Diffuseur
- 3 tubes de 15 ml et 1 tube de 5 ml
- Outil pour retirer le compte-gouttes des bouteilles d'huiles essentielles

Schéma



VEUILLEZ LIRE ATTENTIVEMENT CE MANUEL AVANT L'UTILISATION.

Procédures obligatoires de sécurité

- Ne jamais utiliser ce diffuseur à d'autres fins que celles indiquées dans ce manuel.
- Lire le manuel d'utilisation avant d'utiliser ce diffuseur.
- Retirer tous les emballages avant utilisation.
- Avant tout entreposage prolongé, veillez à retirer la bouteille d'huile essentielle et à nettoyer le diffuseur.

AVERTISSEMENT: Lisez et suivez attentivement ces instructions.


- Ce diffuseur n'est pas destiné à être utilisé par des personnes aux capacités physiques ou cognitives réduites sans expérience préalable avec le diffuseur, sauf si elles ont reçu une formation sur l'utilisation correcte du diffuseur de la part d'une personne responsable de leur sécurité et qui comprend les risques encourus.
- Ne pas modifier, réparer ou désassembler ce diffuseur, sous risque d'incendie, d'électrocution ou d'endommagement.
- Ne pas exposer la prise à l'eau, sous peine de brûlures.
- Ne placez pas vos doigts ou d'autres objets dans la fente de la prise.
- Cesser immédiatement d'utiliser le diffuseur et débrancher la prise si de la fumée, des odeurs inhabituelles, des bruits inhabituels ou d'autres anomalies apparaissent.
- Éviter de faire couler de l'huile essentielle sur l'extérieur du diffuseur ou sur des meubles. En cas d'écoulement accidentel, l'essuyer immédiatement pour éviter de décolorer l'extérieur du diffuseur ou du meuble.
- Ce diffuseur n'est pas un équipement médical. Il n'est pas recommandé d'inhaler directement la brume d'arôme qui s'échappe de la buse.
- Ne pas renverser le diffuseur lorsque l'huile est dans l'atomiseur ; l'huile pourrait s'écouler.

AVERTISSEMENT SUR DES INSTRUCTIONS DE SÉCURITÉ IMPORTANTES

Lors de l'utilisation de produits électriques, des précautions de base doivent toujours être prises, dont les suivantes :

- a) Lire toutes les instructions avant d'utiliser le produit.
- b) Pour réduire le risque de blessure, une surveillance étroite est nécessaire lorsqu'un produit est utilisé à proximité d'enfants.
- c) Ne pas mettre les doigts ou les mains dans le produit.

CONSERVER CES INSTRUCTIONS




Mettre l'huile dans votre diffuseur LunaMist

1. Sélectionnez le tube approprié en fonction de la hauteur de votre bouteille d'huile essentielle.
2. Placez le tube au fond de l'embout.
3. Si la bouteille d'huile essentielle est équipée d'un compte-gouttes, veuillez utiliser l'outil fourni pour l'enlever.
4. Vissez l'embout sur la bouteille avec le tube inséré dans la bouteille.
5. Alignez les flèches sur l'embout et le diffuseur. L'embout doit descendre facilement. **NE PAS FORCER LA BUSE VERS LE BAS.**
6. Appuyer doucement sur la buse jusqu'à ce que vous sentiez un déclic et que l'appareil soit prêt à diffuser.

À noter: ce diffuseur LunaMist fonctionne mieux avec des huiles à faible viscosité. Ne diffusez pas d'huiles contenant de l'huile de noix de coco, car cela pourrait obstruer l'atomiseur.


Mise en marche de votre diffuseur




Temps

Vous pouvez choisir la durée de fonctionnement de votre diffuseur:

- 1 heure
- 2 heures
- 4 heures
- 8 heures
- Le diffuseur fonctionne en continu lorsqu'aucun voyant de durée de fonctionnement n'est allumé.



Mode de diffusion



Faible
Moyen
Élevé

Faible : 3 minutes au début, 1 minute toutes les 5 minutes

Moyen : 5 min au départ, 2 min toutes les 4 minutes


Élevé : 7 min au début, 3 min toutes les 3 minutes

Veilleuse

Pour allumer la lumière, appuyez sur le bouton de la veilleuse (Night Light).

Pour éteindre la lumière, appuyez une fois sur le bouton de la veilleuse (Night Light).

À noter : la lumière ne s'active que lorsque la pièce est sombre.



Se connecter à l'application AromaCare de Young Living

1. Accédez à l'App Store (Apple) ou au Google Play Store (Android).
2. Téléchargez l'application AromaConnect de Young Living.
3. Connectez-vous à l'application et créez un identifiant.
4. Assurez-vous d'avoir activé le Bluetooth sur votre téléphone et que celui-ci est connecté à un réseau Wi-Fi 2,4 GHz avant de jumeler votre appareil mobile à votre diffuseur. La plupart des appareils domestiques intelligents ne peuvent se connecter qu'au Wi-Fi 2,4 GHz. Si vous essayez de jumeler votre appareil à un signal 5 GHz, il se peut que vous ayez des difficultés à vous connecter. Pour vous assurer que votre appareil s'associe correctement, vérifiez que vous l'associez à un réseau Wi-Fi de 2,4 GHz. Appuyez sur le bouton d'alimentation de votre diffuseur et maintenez-le enfoncé pendant environ 3 à 5 secondes. Une fois que la lumière commence à clignoter, le mode connexion est activé et vous pouvez relâcher le bouton.
5. Une fois le diffuseur jumelé à votre appareil mobile, suivez les instructions de l'application.

Nettoyage et entretien

- Les huiles peuvent décolorer certaines parties du diffuseur. Veillez à essuyer tout excès d'huile sur votre appareil.
- Pour obtenir la meilleure performance et les meilleurs résultats, nettoyez l'embout 1 à 2 fois par semaine ou lorsque vous changez l'huile essentielle.
- N'utilisez que des huiles essentielles de première qualité pour éviter d'endommager les composants du diffuseur.

Comment nettoyer votre diffuseur:

1. Appuyez sur l'atomiseur et soulevez-le du diffuseur LunaMist.
2. Dévissez la bouteille d'huile de l'atomiseur.
3. Mettre un peu d'alcool à friction dans une bouteille d'huile essentielle vide.
4. Vissez l'atomiseur sur la bouteille d'huile.
5. Poussez l'atomiseur vers le bas dans le diffuseur LunaMist.
6. Dans un endroit bien ventilé, mettez l'appareil en mode "H" pendant 30 minutes, puis le faire fonctionner en utilisant la bouteille contenant de l'alcool à friction pendant 10 minutes.
7. Retirez la bouteille avec l'alcool, remettez en place une bouteille contenant votre huile essentielle préférée et appréciez.

Dépannage

Si votre diffuseur ne fonctionne pas de manière adéquate, veuillez suivre les instructions de dépannage ci-dessous.

Statut	Cause(s)	Solution(s)
Il n'y a pas de brume/peu de brume lorsque le diffuseur est en marche.	L'huile essentielle est vide.	Remplir le réservoir avec la quantité appropriée d'huile essentielle ou le remplacer par une nouvelle huile essentielle.
	La paille est mal installée ou n'est pas de la bonne taille.	Retirer et réinstaller la paille. Veiller à utiliser la bonne paille.
	Le diffuseur n'a pas été mis en marche depuis longtemps.	Suivre les instructions de nettoyage et d'entretien.
	Il y a de la poussière sur l'atomiseur.	
	L'atomiseur n'est pas placé correctement	Vérifier le sens de l'atomiseur et l'installer correctement.
Le diffuseur ne se met pas en marche	L'adaptateur n'a pas été correctement installé dans la prise de courant.	Détacher et réinstaller correctement l'alimentation dans la prise de courant.
L'huile coule	La buse de diffusion n'est pas orientée vers le haut ou vers le bas	Veillez à ce que la buse de brume soit toujours orientée vers le haut.
Le diffuseur dégage des odeurs inhabituelles	L'atomiseur dégage une odeur bizarre	Suivre les instructions de nettoyage et d'entretien.
	L'huile essentielle n'est pas propre ou a été entreposée pendant une longue période.	Remplacer l'huile essentielle du diffuseur par une huile en bon état.
La connexion Wi-Fi n'est pas disponible	Mauvaise connexion internet.	Vérifier l'état de l'internet ou de l'application.
	Le bouton d'alimentation ne clignote pas après une longue pression.	Vérifier si l'alimentation fonctionne ou non, ou redémarrer le diffuseur.

Spécifications de l'appareil

Nom du produit :	Diffuseur à brancher AromaConnect ^{MC} LunaMist ^{MC} 44098
N° d'article :	
Dimensions :	103 x 81,2 x 125,3 mm / 4,06 x 3,20 x 4,93 pouces
Matériel :	Polypropylène (PP)
Source d'alimentation :	CA 100-240 V
Capacité de la bouteille d'huile :	Bouteille de 5 à 15 ml
Diamètre des particules atomisées :	moins de 3,3 UM (micromètre)
Zone de couverture :	Jusqu'à 35 m ² , en fonction de la hauteur de plafond, de la ventilation, etc.
Temps de diffusion :	1 heure, 2 heures, 4 heures, 8 heures ou en continu

Garantie des diffuseurs Young Living

Young Living Essential Oils (YLEO), 1538 W. Sandalwood Dr., Lehi, UT 84043, sous réserve des exclusions ci-dessous, garantit que son diffuseur est exempt de défauts de matériaux et de fabrication dans le cadre d'une utilisation normale par le consommateur pendant 12 mois à compter de la date d'achat initiale.

La présente garantie ne couvre pas:

1. Les défauts ou dommages résultant d'une utilisation du diffuseur non conforme à son utilisation prévue ;
2. Les défauts ou dommages résultant d'une mauvaise utilisation, d'un accident ou d'une négligence ;
3. Les défauts ou dommages résultant de l'utilisation d'huiles autres que celles fournies ou vendues par Young Living Essential Oils ou un distributeur agréé ;
4. Les défauts ou dommages résultant de l'utilisation de matériaux autres que les huiles essentielles ;

5. Les défauts ou dommages résultant d'un test, d'un fonctionnement, d'un entretien, d'une installation, d'un réglage ou d'une altération ou modification de quelque nature que ce soit ;
6. Rupture ou dommage causé par l'utilisation d'une tension autre que celle spécifiée ;
7. Produits démontés ou réparés par toute personne autre qu'un agent agréé par Young Living Essential Oils de manière à affecter négativement les performances ou à empêcher une inspection, une vérification et un test adéquats pour vérifier toute réclamation au titre de la garantie. Si le diffuseur présente des signes d'ouverture, la garantie sera annulée.
8. Les produits dont l'étiquette a été retirée ou dont le numéro de série est illisible ;
9. Les marques, telles que les rayures, sur les surfaces en plastique et les parties exposées à l'extérieur, résultant d'une utilisation normale ;
10. Les dommages résultant d'une usure normale ;
11. Les dommages résultant de l'utilisation d'outils métalliques pour nettoyer l'appareil.

Cette garantie limitée est le recours exclusif de l'acheteur et s'applique aux nouveaux diffuseurs achetés auprès de Young Living Essential Oils et n'est pas transférable. Veuillez conserver votre facture d'achat originale. En cas de réclamation au titre de la garantie ou de retour pour réparation, une copie de la facture d'achat doit accompagner le diffuseur lorsqu'il est renvoyé à Young Living Essential Oils.

Pour faire une demande de garantie ou pour acheter des pièces de rechange, veuillez contacter les services aux membres de Young Living. Si les services aux membres déterminent que le diffuseur doit être renvoyé à YLEO, l'acheteur devra renvoyer le produit dans sa boîte d'origine (si disponible) avec l'adaptateur d'alimentation, une copie du reçu d'achat original et le numéro d'autorisation de retour de marchandise (RMA#) de YLEO clairement affiché sur le reçu, qui sera fourni par les services aux membres.

Services aux membres australiens:

1300 289 536 ou 02 8650 0000
custserv@youngliving.com.au

Services aux membres canadiens:

1-855-429-2616

cxcanada@youngliving.com

Livraison en Australie:

Retour de produits Young Living /RMA# _____

PO Box 7707

Baulkham Hills BC

NSW 2153

Livraison au Canada:

Young Living Essential Oils/RMA# _____

Suite 142 701 64 Ave. SE

Calgary, AB T2H 2C3

Pour en savoir plus sur notre politique de retour, consultez l'adresse suivante
YoungLiving.com.

AVIS:

Veillez à remplir le formulaire de retour YLEO et à renvoyer tous les éléments énumérés pour que votre retour soit traité dans les meilleurs délais. Si YLEO a déterminé, sur la base d'une évaluation et d'une inspection du diffuseur, que le défaut ou le dysfonctionnement est couvert par la garantie, YLEO enverra un diffuseur de remplacement sans frais supplémentaires. En cas de rupture de stock du diffuseur à brancher LunaMist, YLEO offrira la possibilité de l'échanger contre un autre diffuseur de valeur comparable ou de bénéficier d'un crédit sur les produits Young Living.

Cet appareil est conforme à la partie 15 des règles de la FCC. Son fonctionnement est soumis aux deux conditions suivantes:

- (1) Cet appareil ne doit pas provoquer d'interférences nuisibles, et
- (2) cet appareil doit accepter toute interférence reçue, y compris les interférences susceptibles de provoquer un fonctionnement indésirable

REMARQUE : cet équipement a été testé et déclaré conforme aux limites imposées aux appareils numériques de classe B, conformément à la partie 15 des règles de la FCC. Ces limites sont conçues pour fournir une protection raisonnable contre les interférences nuisibles dans une installation résidentielle. Cet équipement génère, utilise et peut émettre des fréquences radio et, s'il n'est pas installé et utilisé conformément aux instructions, il peut provoquer des

interférences nuisibles aux communications radio. Cependant, il n'y a aucune garantie qu'il n'y aura pas d'interférences dans une installation particulière. Si cet équipement provoque des interférences nuisibles à la réception de la radio ou de la télévision, ce qui peut être déterminé en éteignant et en allumant l'équipement, l'utilisateur est encouragé à essayer de corriger les interférences en prenant une ou plusieurs des mesures suivantes:

- Réorienter ou déplacer l'antenne de réception.
- Augmenter la distance entre l'appareil et le récepteur.
- Brancher l'appareil sur une prise de courant située sur un circuit différent de celui sur lequel le récepteur est branché.
- Consulter le revendeur ou un technicien radio/TV expérimenté pour obtenir de l'aide

Tout changement ou modification non expressément approuvé par la partie responsable de la conformité peut annuler le droit de l'utilisateur à faire fonctionner l'équipement.

L'appareil a été évalué pour répondre aux exigences générales en matière d'exposition aux radiofréquences.

L'appareil peut être utilisé sans restriction dans des conditions d'exposition portable.

Déclaration d'exposition aux radiations de la FCC:

L'appareil est conforme aux limites d'exposition aux radiations fixées par la FCC pour un environnement non contrôlé. Cet équipement doit être installé et utilisé avec une distance minimale de 20 centimètres entre le radiateur et votre corps.



Cet appareil est conforme aux normes RSS exemptée de licence d'Industrie Canada.

Le fonctionnement est soumis aux deux conditions suivantes:

- (1) Cet appareil ne doit pas provoquer d'interférences, et
- (2) Cet appareil doit accepter toute interférence, y compris les interférences susceptibles de provoquer un fonctionnement indésirable de l'appareil.

Cet équipement est conforme aux limites d'exposition au rayonnement de radiofréquence de l'IC fixées pour un environnement non contrôlé.

Cet appareil doit être installé et utilisé avec une distance minimale de 20 centimètres entre le radiateur et votre corps.



1538 W. Sandalwood Drive
Lehi, UT 84043
YoungLiving.com

Designed for
Young Living Essential Oils

Manufacturer:
Majestic-M&A International Co. Ltd.

Conçu pour
Young Living Essential Oils

Fabricant :
Majestic-M&A International Co. Ltd.